



Level



Pressure



Flow



Temperature



Liquid Analysis



Registration



Systems Components



Services



Solutions

Description of Device Functions

Proline Prosonic Flow 90

Ultrasonic Flow Measuring System




Table of Contents

1	Function matrix Prosonic Flow 90	7
1.1	The function matrix: layout and use	7
1.2	Illustration of the function matrix	8
2	Group MEASURING VALUES	9
3	Group SYSTEM UNITS	10
4	Group QUICK SETUP	13
4.1	Quick Setup "Sensor"	14
4.2	Quick Setup "Commissioning"	16
5	Group OPERATION	18
6	Group USER INTERFACE	20
7	Group TOTALIZER 1...2	23
8	Group HANDLING TOTALIZER	25
9	Group CURRENT OUTPUT	26
10	Group PULSE/FREQUENCY OUTPUT	31
11	Group STATUS OUTPUT	42
11.1	Information on the response of the status output	45
11.2	Switching action of the status output	45
12	Group STATUS INPUT	47
13	Group COMMUNICATION	49
14	Group PROCESS PARAMETER	50
15	Group PIPE DATA	52
16	Group LIQUID DATA	55
17	Group SYSTEM PARAMETERS	58
18	Group SENSOR DATA	61
19	Group CALIBRATION DATA	63

20	Group SUPERVISION	64
21	Group SIMULATION SYSTEM	66
22	Group SENSOR VERSION	67
23	Group AMPLIFIER VERSION	67
24	Factory settings	68
24.1	SI units	68
24.2	US units (for USA and Canada only)	68
24.3	Language	68

Registered trademarks
HART®
Registered trademark of the HART Communication Foundation, Austin, USA

1 Function matrix Prosonic Flow 90

1.1 The function matrix: layout and use

The function matrix is a two-level construct: the groups form one level and the groups' functions the other.

The groups are the “highest-level grouping” of the operating options for the measuring device. A number of functions is assigned to each group.

You select a group in order to access the individual functions for operating and parameterizing the measuring device.


An overview of all the groups available is provided in the table of contents on page 3 and in the graphical representation of the function matrix on Page 8.

An overview of all the functions available is provided on Page 8, complete with page references to the detailed function descriptions.



The descriptions of the individual functions start on Page 9.

Example of how to parameterize a function (in this case changing the language for the UI):

- ① Enter into the function matrix (E-key).
- ② Select the OPERATION group.
- ③ Select the LANGUAGE function, change the setting from ENGLISH to DEUTSCH (+/-) and save E (all text on the display now appears in German).
- ④ Exit the function matrix (ESC > 3 seconds).





2 Group MEASURING VALUES

Function description MEASURING VALUES	
<p> Note!</p> <ul style="list-style-type: none"> ■ The engineering unit of the measured variable displayed here can be set in the SYSTEM UNITS group, (see Page 10). ■ If the fluid in the pipe flows backwards, a negative sign prefixes the flow reading on the display. 	
VOLUME FLOW	<p>The volume flow currently measured appears on the display.</p> <p>Display: 5-digit floating-point number, including unit and sign (z.B. 5.5445 dm³/min; 1.4359 m³/h; -731.63 gal/d; usw.)</p>
SOUND VELOCITY	<p>The current measured sound velocity in the liquid appears on the display.</p> <p>Display: 5-digit fixed-point number, incl. unit (e.g. 1400.0 m/s, 5249.3 ft/s)</p>
FLOW VELOCITY	<p>The flow velocity currently measured appears on the display.</p> <p>Display: 5-digit floating-point number, including unit and sign (e.g. 8.0000 m/s, 26.247 ft/s)</p>
SIGNAL STRENGTH	<p>The signal strength appears on the display.</p> <p>Display: 4-digit fixed-point number (e.g. 80.0)</p> <p> Note! To ensure reliable measurement takes place, Prosonic Flow requires a signal strength of > 30.</p>



3 Group SYSTEM UNITS

Function description SYSTEM UNITS	
Use this function group to select the unit for the measured variable.	
UNIT VOLUME FLOW	<p>Use this function to select the unit for displaying the volume flow.</p> <p>The unit you select here is also valid for:</p> <ul style="list-style-type: none"> ■ Current output ■ Frequency output ■ Switch points (limit value for volume flow, flow direction) ■ Low flow cut off <p>Options:</p> <p>Metric:</p> <p>Cubic centimeter → cm³/s; cm³/min; cm³/h; cm³/day Cubic decimeter → dm³/s; dm³/min; dm³/h; dm³/day Cubic meter → m³/s; m³/min; m³/h; m³/day Milliliter → ml/s; ml/min; ml/h; ml/day Liter → l/s; l/min; l/h; l/day Hectoliter → hl/s; hl/min; hl/h; hl/day Megaliter → Ml/s; Ml/min; Ml/h; Ml/day</p> <p>US:</p> <p>Cubic centimeter → cc/s; cc/min; cc/h; cc/day Acre foot → af/s; af/min; af/h; af/day Cubic foot → ft³/s; ft³/min; ft³/h; ft³/day Fluid ounce → oz f/s; oz f/min; oz f/h; oz f/day Gallon → gal/s; gal/min; gal/h; gal/day Million gallons → Mgal/s; Mgal/min; Mgal/h; Mgal/day Barrel (normal fluids: 31.5 gal/bbl) → bbl/s; bbl/min; bbl/h; bbl/day Barrel (beer: 31.0 gal/bbl) → bbl/s; bbl/min; bbl/h; bbl/day Barrel (petrochemicals: 42.0 gal/bbl) → bbl/s; bbl/min; bbl/h; bbl/day Barrel (filling tanks: 55.0 gal/bbl) → bbl/s; bbl/min; bbl/h; bbl/day</p> <p>Imperial</p> <p>Gallon → gal/s; gal/min; gal/h; gal/day Mega gallon → Mgal/s; Mgal/min; Mgal/h; Mgal/day Barrel (beer: 36.0 gal/bbl) → bbl/s; bbl/min; bbl/h; bbl/day Barrel (petrochemicals: 34.97 gal/bbl) → bbl/s; bbl/min; bbl/h; bbl/day</p> <p>Factory setting: l/s</p>

Function description SYSTEM UNITS	
UNIT VOLUME	<p>Use this function to select the unit for displaying the volume.</p> <p>The unit you select here is also valid for:</p> <ul style="list-style-type: none"> ■ Pulse weighting (e.g. m³/p) <p>Options: Metric → cm³; dm³; m³; ml; l; hl; Ml US → cc; af; ft³; oz f; gal; Mgal; bbl (normal fluids); bbl (beer); bbl (petrochemicals) → bbl (filling tanks) Imperial → gal; Mgal; bbl (beer); bbl (petrochemicals)</p> <p>Factory setting: liter</p> <p> Note! The unit of the totalizers is independent of your choice here. The unit for each totalizer is selected separately for the totalizer in question.</p>
UNIT TEMPERATURE	<p>Use this function to select the unit for the liquid temperature.</p> <p> Note! The liquid temperature is entered in the function TEMPERATURE (“QUICK SETUP” for rapid commissioning 55).</p> <p>Options: °C (Celsius) K (Kelvin) °F (Fahrenheit) R (Rankine)</p> <p>Factory setting: °C</p>
UNIT VISCOSITY	<p>Use this function to select the unit for liquid viscosity.</p> <p>Options: mm²/s cSt St</p> <p>Factory setting: mm²/s</p>
UNIT LENGTH	<p>Use this function to select the unit for the measure of length.</p> <p>The unit you select here is valid for:</p> <ul style="list-style-type: none"> ■ Nominal diameter ■ Diameter ■ Wall thickness ■ Liner thickness ■ Path length ■ Wire length ■ Sensor spacing <p>Options: MILLIMETER INCH</p> <p>Factory setting: MILLIMETER</p>

Function description SYSTEM UNITS	
UNIT VELOCITY	<p>Use this function to select the unit for velocity. The unit you select here is valid for:</p> <ul style="list-style-type: none">■ Sound velocity■ Flow velocity <p>Options: m/s ft/s</p> <p>Factory setting: m/s</p>


4 Group QUICK SETUP

Function description QUICK SETUP	
QUICK SETUP SENSOR	<p>Use this function to start the Quick Setup menu for assembling the ultrasonic sensors.</p> <p>Options: YES NO</p> <p>Factory setting: NO</p> <p> Note! You will find a flowchart of the Quick Setup SENSOR menu on Page 14. For more information on Setup menus, please refer to the accompanying Operating Instructions Proline Prosonic Flow 90 (BA 068D/06/en/...)</p>
QUICK SETUP COMMISSIONING	<p>Use this function to start the Quick Setup menu for commissioning.</p> <p>Options: YES NO</p> <p>Factory setting: NO</p> <p> Note! You will find a flowchart of the Quick Setup menu COMMISSIONING on Page 16. For more information on Quick Setup menus, please refer to the accompanying Operating Instructions Proline Prosonic Flow 90 (BA 068D/06/en/...)</p>

4.1 Quick Setup “Sensor”

If the measuring device is equipped with a local operation, the sensor distance can be ascertained using the “Sensor” Quick Setup menu.

If a measuring device does not have a local operation, the individual parameters and functions must be configured via the configuration program ToF Tool - Fieldtool Package.



**Note!**

The display returns to the QUICK SETUP COMMISSIONING function cell if you press the ESC key ( ) during parameter interrogation.

①

Selection of the system units only influences the functions UNIT TEMPERATURE, UNIT LENGTH and UNIT VELOCITY.

②

The POSITION SENSOR function only appears when the CLAMP ON option is set in the MEASUREMENT function and the number of traverses is 2 or 4 in the SENSOR CONFIGURATION function.


③

The WIRE LENGTH function only appears when the CLAMP ON option is set in the MEASUREMENT function and the number of traverses is 1 or 3 in the SENSOR CONFIGURATION function.

4.2 Quick Setup “Commissioning”

If the measuring device is equipped with a local operation, all the device parameters important for standard measuring mode can be configured easily and quickly using the “Commissioning” Quick Setup menu.

If a measuring device does not have a local operation, the individual parameters and functions must be configured via the configuration program ToF Tool - Fieldtool Package.



F06-90xxxxx-19-xx-xx-en-000

**Note!**

The display returns to the QUICK SETUP COMMISSIONING cell if you press the ESC key combination during interrogation.

①

Only the units not yet configured in the current Quick Setup are offered for selection in each cycle. The unit for volume is derived from the volume flow unit.

②

The “YES” option remains visible until all the units have been parameterized. “NO” is the only option displayed when no further units are available.




③




Only the outputs not yet configured in the current Quick Setup are offered for selection in each cycle.

④


The “YES” option remains visible until all the outputs have been parameterized. “NO” is the only option displayed when no further outputs are available.



5 Group OPERATION

Function description OPERATION																																							
LANGUAGE	<p>Use this function to select the language for all texts, parameters and messages shown on the local display.</p> <p> Note! The displayed options depend on the available language group shown in the LANGUAGE GROUP function.</p> <p>Options:</p> <table> <tr> <td>Language group</td> <td>ENGLISH</td> </tr> <tr> <td>WEST EU / USA</td> <td>DEUTSCH</td> </tr> <tr> <td></td> <td>FRANCAIS</td> </tr> <tr> <td></td> <td>ESPANOL</td> </tr> <tr> <td></td> <td>ITALIANO</td> </tr> <tr> <td></td> <td>NEDERLANDS</td> </tr> <tr> <td></td> <td>PORTUGUESE</td> </tr> <tr> <td>Language group</td> <td>ENGLISH</td> </tr> <tr> <td>EAST EU / SCAND</td> <td>NORSK</td> </tr> <tr> <td></td> <td>SVENSKA</td> </tr> <tr> <td></td> <td>SUOMI</td> </tr> <tr> <td></td> <td>POLISH</td> </tr> <tr> <td></td> <td>CZECH</td> </tr> <tr> <td></td> <td>RUSSIAN</td> </tr> <tr> <td>Language group ASIA</td> <td>ENGLISH</td> </tr> <tr> <td></td> <td>BAHASA INDONESIA</td> </tr> <tr> <td></td> <td>JAPANESE (syllabary)</td> </tr> <tr> <td>Language group</td> <td>CHINESE</td> </tr> <tr> <td>CHINESE</td> <td>ENGLISH</td> </tr> <p>Factory setting: Country-dependent, see Page 68</p> <p> Note!</p> <ul style="list-style-type: none"> ■ If you press the -keys simultaneously during startup, the language defaults to "ENGLISH". ■ You can change the language group via the configuration software ToF Tool - Fieldtool Package. Please do not hesitate to contact your Endress+Hauser sales office if you have any questions. </table>	Language group	ENGLISH	WEST EU / USA	DEUTSCH		FRANCAIS		ESPANOL		ITALIANO		NEDERLANDS		PORTUGUESE	Language group	ENGLISH	EAST EU / SCAND	NORSK		SVENSKA		SUOMI		POLISH		CZECH		RUSSIAN	Language group ASIA	ENGLISH		BAHASA INDONESIA		JAPANESE (syllabary)	Language group	CHINESE	CHINESE	ENGLISH
Language group	ENGLISH																																						
WEST EU / USA	DEUTSCH																																						
	FRANCAIS																																						
	ESPANOL																																						
	ITALIANO																																						
	NEDERLANDS																																						
	PORTUGUESE																																						
Language group	ENGLISH																																						
EAST EU / SCAND	NORSK																																						
	SVENSKA																																						
	SUOMI																																						
	POLISH																																						
	CZECH																																						
	RUSSIAN																																						
Language group ASIA	ENGLISH																																						
	BAHASA INDONESIA																																						
	JAPANESE (syllabary)																																						
Language group	CHINESE																																						
CHINESE	ENGLISH																																						

Function description OPERATION	
ACCESS CODE	<p>All data of the measuring system are protected against inadvertent change. Programming is disabled and the settings cannot be changed until a code is entered in this function. If you press the /[-] keys in any function, the measuring system automatically goes to this function and the prompt to enter the code appears on the display (when programming is disabled).</p> <p>You can enable programming by entering your personal code (factory setting = 90, see function DEF. PRIVATE CODE on Page 19)</p> <p>User input: max. 4-digit number: 0...9999</p> <p> Note!</p> <ul style="list-style-type: none"> ■ The programming levels are disabled if you do not press a key within 60 seconds following automatic return to the HOME position. ■ You can also disable programming in this function by entering any number (other than the defined private code). ■ The Endress+Hauser service organization can be of assistance if you mislay your personal code.
DEF. PRIVATE CODE	<p>Use this function to enter a personal code number for enabling programming.</p> <p>User input: 0...9999 (max. 4-digit number)</p> <p>Factory setting: 90</p> <p> Note!</p> <ul style="list-style-type: none"> ■ Programming is always enabled with the code "0". ■ Programming has to be enabled before this code can be changed. When programming is disabled this function is not available, thus preventing others from accessing your personal code.
STATUS ACCESS	<p>Use this function to check the access status for the function matrix.</p> <p>Display: ACCESS CUSTOMER (parameterization possible) LOCKED (parameterization disabled)</p>
ACCESS CODE COUNTER	<p>The number of times the private or service code was entered to access the device appears on the display.</p> <p>Display: Integer (delivery status: 0)</p>



6 Group USER INTERFACE


Function description USER INTERFACE	
ASSIGN LINE 1	<p>Use this function to define which display value is assigned to the main line (top line of the local display) during normal measuring operation.</p> <p>Options: OFF VOLUME FLOW VOLUME FLOW IN % SOUND VELOCITY FLOW VELOCITY</p> <p>Factory setting: VOLUME FLOW</p>
ASSIGN LINE 2	<p>Use this function to define which display value is assigned to the additional line (bottom line of the local display) for display during normal measuring operation.</p> <p>Options: OFF VOLUME FLOW VOLUME FLOW IN % SOUND VELOCITY FLOW VELOCITY TOTALIZER TAG NAME OPERATING/SYSTEM CONDITION DISPLAY FLOW DIRECTION VOLUME FLOW BARGRAPH IN % SIGNAL STRENGTH BARGRAPH IN %</p> <p>Factory setting: TOTALIZER</p>
100% VALUE	<p> Note! This function is only available if VOLUME FLOW IN % or VOLUME FLOW BARGRAPH IN % was selected in the function ASSIGN LINE 1 or ASSIGN LINE 2.</p> <p>Use this function to define the flow value which should be shown on the display as the 100% value.</p> <p>User input: 5-digit floating-point number</p> <p>Factory setting: 10 l/s</p>

Function description USER INTERFACE	
FORMAT	<p>Use this function to define the maximum number of places after the decimal point displayed for the reading in the main line.</p> <p>Options: XXXXX. - XXXX.X - XXX.XX - XX.XXX -X.XXXX</p> <p>Factory setting: X.XXXX</p> <p> Note!</p> <ul style="list-style-type: none"> ■ Note that this setting only affects the reading as it appears on the display, it has no influence on the accuracy of the system's calculations. ■ The places after the decimal point as computed by the measuring device cannot always be displayed, depending on this setting and the engineering unit. In these instances an arrow appears on the display between the measuring value and the engineering unit (e.g. 1.2 → m³/h), indicating that the measuring system is computing with more decimal places than can be shown on the display.
DISPLAY DAMPING	<p>Use this function to enter a time constant defining how the display reacts to severely fluctuating flow variables, either very quickly (enter a low time constant) or with damping (enter a high time constant).</p> <p>User input: 0...100 seconds</p> <p>Factory setting: 1 s</p> <p> Note! Setting the time constant to zero seconds switches off damping.</p>
CONTRAST LCD	<p>Use this function to optimize display contrast to suit local operating conditions.</p> <p>User input: 10...100%</p> <p>Factory setting: 50%</p>
BACKLIGHT	<p>Use this function to optimize the backlight to suit local operating conditions.</p> <p>User input: 10...100%</p> <p>Factory setting: 50%</p>


Function description USER INTERFACE	
TEST DISPLAY	<p>Use this function to test the operability of the local display and its pixels.</p> <p>Options: OFF ON</p> <p>Factory setting: OFF</p> <p>Test sequence:</p> <ol style="list-style-type: none">1. Start the test by selecting ON.2. All pixels of the main line and additional line are darkened for at least 0.75 seconds.3. The main line and additional line show an "8" in each field for at least 0.75 seconds.4. The main line and additional line show a "0" in each field for at least 0.75 seconds.5. The main line and additional line show nothing (blank display) for at least 0.75 seconds. <p>When the test is completed the local display returns to its initial state and the setting changes to OFF.</p>

7 Group TOTALIZER 1...2


Function description TOTALIZER 1...2	
ASSIGN TOTALIZER	<p>Use this function to assign a measured variable (volume flow) to the totalizer.</p> <p>Options: OFF VOLUME FLOW</p> <p>Factory setting: VOLUME FLOW</p> <p> Note! The totalizer is reset to "0" as soon as the selection is changed.</p>
SUM	<p>The total for the totalizer's measured variable aggregated since measuring commenced appears on the display. This value can be positive or negative, depending on the direction of flow.</p> <p>Display: max. 7-digit floating-point number, including sign and unit (e.g. 15467.04 m³)</p> <p> Note! The totalizer's response to faults is defined in the function "FAILSAFE MODE", (see Page 25).</p>
OVERFLOW	<p>The total for the totalizer's overflow aggregated since measuring commenced appears on the display.</p> <p>Total flow quantity is represented by a floating-point number consisting of max. 7 digits. You can use this function to view higher numerical values (>9,999,999) as overflows. The effective quantity is thus the total of the function OVERFLOW plus the value displayed in the function SUM.</p> <p>Example: Reading for 2 overflows: 2 E7 dm³ (= 20 dm³) The value displayed in the function "SUM" = 196,845.7 dm³ Effective total quantity = 20,196,845.7 dm³</p> <p>Display: Integer with exponent, including sign and unit, e.g. 2 E7 dm³</p>
UNIT TOTALIZER	<p>Use this function to define the unit for the totalizer.</p> <p>Options: Metric → cm³; dm³; m³; ml; l; hl; Ml</p> <p>US → cc; af; ft³; oz f; gal; Mgal; bbl (normal fluids); bbl (beer); bbl (petrochemicals); bbl (filling tanks)</p> <p>Imperial → gal; Mgal; bbl (beer); bbl (petrochemicals)</p> <p>Factory setting: m³</p>



Function description TOTALIZER 1...2	
TOTALIZER MODE	<p>Use this function to define how the flow components are to be totaled by the totalizer in question.</p> <p>Options: BALANCE Positive and negative flow components. The positive and negative flow components are balanced. In other words, net flow in the flow direction is registered.</p> <p>FORWARD Positive flow components only</p> <p>REVERSE Negative flow components only</p> <p>Factory setting: Totalizer 1 = BALANCE Totalizer 2 = FORWARD</p>
RESET TOTALIZER	<p>Use this function to reset the sum and the overflow of the totalizer to “zero” (= RESET).</p> <p>Options: NO YES</p> <p>Factory setting: NO</p> <p> Note! If the device is equipped with a status input and if it is appropriately configured, totalizer resetting can also be triggered by a pulse.</p>





8 Group HANDLING TOTALIZER



Functional description	
RESET ALL TOTALIZERS	<p>Use this function to reset the totals (including all overflows) of the totalizers (1...2) to "zero" (= RESET).</p> <p>Options: NO YES</p> <p>Factory setting: NO</p> <p> Note! If the device is equipped with a status input and if it is appropriately configured, a reset for the totalizer (1...2) can also be triggered by a pulse (see function ASSIGN STATUS IN).</p>
FAILSAFE ALL TOTALIZERS	<p>Use this function to define the common response of all totalizers (1...2) in case of error.</p> <p>Options: STOP The totalizer is paused until the fault is rectified.</p> <p>ACTUAL VALUE The totalizer continues to count based on the current flow measuring value. The fault is ignored.</p> <p>HOLD VALUE The totalizer continues to count the flow is based on the last valid flow value (before the fault occurred).</p> <p>Factory setting: STOP</p>



9 Group CURRENT OUTPUT

Function description CURRENT OUTPUT	
ASSIGN CURRENT OUTPUT	<p>Use this function to assign a measured variable to the current output.</p> <p>Options: OFF VOLUME FLOW SOUND VELOCITY FLOW VELOCITY</p> <p>Factory setting: VOLUME FLOW</p> <p> Note! If you select OFF, the only function shown in this group is the function ASSIGN CURRENT OUTPUT.</p>





Function description CURRENT OUTPUT																																													
CURRENT SPAN	<p>Use this function to define the current span. The selection specifies the operational range and the lower and upper signal on alarm.</p> <p>Options: 0–20 mA 4–20 mA 4–20 mA HART 4–20 mA NAMUR 4–20 mA HART NAMUR 4–20 mA US 4–20 mA HART US 0–20 mA (25 mA) 4–20 mA (25 mA) 4–20 mA (25 mA) HART</p> <p>Factory setting: 4–20 mA HART NAMUR</p> <p> Note! When switching the hardware from an active (factory setting) to a passive output signal select a current span of 4...20 mA, (see Operating Instructions Proline Prosonic Flow 90, BA 068D/06/en/.)</p> <p>Current span, operational range and signal on alarm level</p> <div style="text-align: center;"> </div> <table border="1" style="margin: 10px auto;"> <thead> <tr> <th>a</th> <th>1</th> <th>2</th> <th>3</th> </tr> </thead> <tbody> <tr> <td>0-20 mA</td> <td>0 - 20.5 mA</td> <td>0</td> <td>22</td> </tr> <tr> <td>4-20 mA</td> <td>4 - 20.5 mA</td> <td>2</td> <td>22</td> </tr> <tr> <td>4-20 mA HART</td> <td>4 - 20.5 mA</td> <td>2</td> <td>22</td> </tr> <tr> <td>4-20 mA NAMUR</td> <td>3.8 - 20.5 mA</td> <td>3.5</td> <td>22.6</td> </tr> <tr> <td>4-20 mA HART NAMUR</td> <td>3.8 - 20.5 mA</td> <td>3.5</td> <td>22.6</td> </tr> <tr> <td>4-20 mA US</td> <td>3.9 - 20.8 mA</td> <td>3.75</td> <td>22.6</td> </tr> <tr> <td>4-20 mA HART US</td> <td>3.9 - 20.8 mA</td> <td>3.75</td> <td>22.6</td> </tr> <tr> <td>0-20 mA (25 mA)</td> <td>0 - 24 mA</td> <td>0</td> <td>25</td> </tr> <tr> <td>4-20 mA (25 mA)</td> <td>4 - 24 mA</td> <td>2</td> <td>25</td> </tr> <tr> <td>4-20 mA (25 mA) HART</td> <td>4 - 24 mA</td> <td>2</td> <td>25</td> </tr> </tbody> </table> <p style="text-align: right; font-size: small;">A0001222</p> <p><i>I = Current span</i> <i>1 = Operational range (measuring information)</i> <i>2 = Lower signal on alarm level</i> <i>3 = Upper signal on alarm level</i></p> <p> Note!</p> <ul style="list-style-type: none"> ■ If the measured value exceeds the measuring range (as defined in the functions VALUE 0_4 mA and VALUE 20 mA) a notice message is generated (#351–354, current span). ■ In case of a fault the behaviour of the current output is according to the selected option in the function FAILSAFE MODE. Change the error category in the function ASSIGN SYSTEM ERROR to generate a fault message instead of a notice message. 	a	1	2	3	0-20 mA	0 - 20.5 mA	0	22	4-20 mA	4 - 20.5 mA	2	22	4-20 mA HART	4 - 20.5 mA	2	22	4-20 mA NAMUR	3.8 - 20.5 mA	3.5	22.6	4-20 mA HART NAMUR	3.8 - 20.5 mA	3.5	22.6	4-20 mA US	3.9 - 20.8 mA	3.75	22.6	4-20 mA HART US	3.9 - 20.8 mA	3.75	22.6	0-20 mA (25 mA)	0 - 24 mA	0	25	4-20 mA (25 mA)	4 - 24 mA	2	25	4-20 mA (25 mA) HART	4 - 24 mA	2	25
a	1	2	3																																										
0-20 mA	0 - 20.5 mA	0	22																																										
4-20 mA	4 - 20.5 mA	2	22																																										
4-20 mA HART	4 - 20.5 mA	2	22																																										
4-20 mA NAMUR	3.8 - 20.5 mA	3.5	22.6																																										
4-20 mA HART NAMUR	3.8 - 20.5 mA	3.5	22.6																																										
4-20 mA US	3.9 - 20.8 mA	3.75	22.6																																										
4-20 mA HART US	3.9 - 20.8 mA	3.75	22.6																																										
0-20 mA (25 mA)	0 - 24 mA	0	25																																										
4-20 mA (25 mA)	4 - 24 mA	2	25																																										
4-20 mA (25 mA) HART	4 - 24 mA	2	25																																										







Function description CURRENT OUTPUT	
VALUE 0_4 mA	<p> Note! This function is not available unless the sound velocity is assigned to the current output.</p> <p>Use this function to assign the 0_4 mA current a value. The value can be greater or less than the value assigned to 20 mA, (function VALUE 20 mA).</p> <p>Example for STANDARD measuring mode:</p> <div style="text-align: center;">  </div> <p style="text-align: right; font-size: small;">A0001223</p> <p>① = Initial value (0...20 mA) ② = Lower signal on alarm level: depends on the setting in the function CURRENT SPAN ③ = Initial value (4...20 mA): depends on the setting in the function CURRENT SPAN ④ = Full scale value (0/4...20 mA): depends on the setting in the function CURRENT SPAN ⑤ = Maximum current value: depends on the setting in the function CURRENT SPAN ⑥ = Failsafe mode (upper signal on alarm level): depends on the setting in the functions CURRENT SPAN (see Page 27) and FAILSAFE MODE, (see Page 29) A = Measuring range (the minimum measuring range has to exceed the value that correlates with a flow velocity of 0.3 m/s)</p> <p>User input: 5-digit floating-point number</p> <p>Factory setting: 0 [unit]</p> <p> Note!</p> <ul style="list-style-type: none"> ■ The appropriate unit is taken from the group SYSTEM UNITS (see Page 10). ■ For details on current span, operational range and signal on alarm level see Page 27.
VALUE 20 mA	<p>Use this function to assign the 20 mA current a value. The value can be greater or less than the value assigned to 0/4 mA, (function VALUE 0_4 mA). Positive and negative values are permissible, depending on the measured variable assigned (e.g. volume flow). The assignment applies for both flow directions for measuring mode SYMMETRY (see Page 58) and only for the selected flow direction for measuring mode STANDARD.</p> <p>User input: 5-digit floating-point number, with sign</p> <p>Factory setting: depends on the setting in the function assign current input: volume flow: 20 l/s sound velocity: 1800 m/s flow velocity: 10 m/s corresponds to the factory setting for the final value.</p> <p> Note!</p> <ul style="list-style-type: none"> ■ The appropriate unit is taken from the group SYSTEM UNITS, (see Page 10). ■ For an example for STANDARD measuring mode See "VALUE 0_4 mA" on Page 28.

Function description CURRENT OUTPUT	
TIME CONSTANT	<p>Use this function to enter a time constant defining how the current output signal reacts to severely fluctuating measured variables, either very quickly (enter a low time constant) or with damping (enter a high time constant).</p> <p>User input: fixed-point number 0.01...100.00 s</p> <p>Factory setting: 1.00 s</p>
FAILSAFE MODE	<p>For safety reasons it is advisable to ensure that the current output assumes a predefined state in the event of a fault. The setting you select affects only the current output. It has no effect on other outputs or the display (e.g. totalizers).</p> <p>Options:</p> <p>MIN. CURRENT The current output adopts the value of the lower signal on alarm level (as defined in the function CURRENT SPAN (4001))</p> <p>MAX. CURRENT The current output adopts the value of the upper signal on alarm level (as defined in the function CURRENT SPAN (4001))</p> <p>HOLD VALUE (not recommended) Measuring value output is based on the last measuring value saved before the error occurred.</p> <p>ACTUAL VALUE Measured value output is based on the current flow measurement. The fault is ignored.</p> <p>Factory setting: MIN. CURRENT</p>
ACTUAL CURRENT	<p>Use this function to view the computed actual value of the output current.</p> <p>Display: 0.00...25.00 mA</p>
SIMULATION CURRENT	<p>Use this function to activate simulation of the current output.</p> <p>Options: OFF ON</p> <p>Factory setting: OFF</p> <p> Note!</p> <ul style="list-style-type: none"> ■ The “SIMULATION CURRENT OUTPUT” message indicates that simulation is active. ■ The measuring device continues to measure while simulation is in progress, i.e. the current measuring values are output correctly via the other outputs. <p> Caution! The setting is not saved if the power supply fails.</p>

Function description CURRENT OUTPUT	
VALUE SIMULATION CURRENT	<p> Note! This function is not available unless the function SIMULATION CURRENT is active (= ON).</p> <p>Use this function to define a selectable value (e.g. 12 mA) to be output at the current output. This is used to test downstream devices and the measuring device itself.</p> <p>User input: Floating-point number: 0.00...25.00 mA</p> <p>Factory setting: 0.00 mA</p> <p> Caution! The setting is not saved if the power supply fails.</p>


10 Group PULSE/FREQUENCY OUTPUT

Function description PULSE/FREQUENCY OUTPUT	
This group is not available unless the measuring device is equipped with a pulse/frequency output.	
OPERATION MODE	<p>Use this function to configure the output as a pulse output or frequency output. The functions available in this function group vary, depending on which option you select here.</p> <p>Options: PULSE FREQUENCY</p> <p>Factory setting: PULSE</p>
ASSIGN FREQUENCY	<p> Note! This function is not available unless the FREQUENCY setting was selected in the function OPERATION MODE.</p> <p>Use this function to assign a measured variable to the frequency output.</p> <p>Options: OFF VOLUME FLOW SOUND VELOCITY FLOW VELOCITY</p> <p>Factory setting: VOLUME FLOW</p> <p> Note! If you select OFF, the only functions shown in this function group are the functions ASSIGN FREQUENCY and OPERATION MODE.</p>
END VALUE FREQ.	<p> Note! This function is not available unless the FREQUENCY setting was selected in the function OPERATION MODE.</p> <p>Use this function to define a full scale frequency for the frequency output. You define the associated measured value of the measuring range in the function VALUE-f HIGH on Page 32.</p> <p>User input: 4-digit fixed-point number 2...1000 Hz</p> <p>Factory setting: 1000 Hz</p> <p>Example:</p> <ul style="list-style-type: none"> ■ VALUE-f HIGH = 1000 l/h, end frequency = 1000 Hz: i.e. at a flow of 1000 l/h, a frequency of 1000 Hz is output. ■ VALUE-f HIGH = 3600 l/h, end frequency = 1000 Hz: i.e. at a flow of 3600 l/h, a frequency of 1000 Hz is output. <p> Note!</p> <ul style="list-style-type: none"> ■ In the FREQUENCY operating mode the output signal is symmetrical (on/off ratio = 1:1). At low frequencies the pulse duration is limited to a maximum of 10 seconds, i.e. the on/off ratio is no longer symmetrical. ■ The start value frequency is always 0 Hz. This value is fixed and cannot be edited.

Function description PULSE/FREQUENCY OUTPUT	
VALUE-f LOW	<p> Note! This function is not available unless FREQUENCY was selected in the OPERATION MODE function and the sound velocity is assigned to the frequency output.</p> <p>Use this function to assign a value to the start value frequency. You define a measuring range by defining VALUE-f LOW and VALUE-f HIGH.</p> <p>User input: 5-digit floating-point number</p> <p>Factory setting: 0 [e.g. m/s]</p> <p> Note!</p> <ul style="list-style-type: none"> ■ The appropriate unit is taken from the group SYSTEM UNITS (see Page 10).
VALUE-f HIGH	<p> Note! This function is not available unless the FREQUENCY setting was selected in the function OPERATION MODE.</p> <p>Use this function to assign a value to the end frequency. Positive and negative values are permissible. The desired measuring range is defined by defining the VALUE-f HIGH. The assignment applies for both flow directions for measuring mode SYMMETRY (see Page 58) and only for the selected flow direction for measuring mode STANDARD.</p> <p>User input: 5-digit floating-point number</p> <p>Factory setting: depends on the setting in the function ASSIGN FREQUENCY: volume flow: 20 l/s sound velocity: 1800 m/s flow velocity: 10 m/s corresponds to the factory setting for the final value.</p> <div style="text-align: center;">  </div> <p style="text-align: right;">A0001279</p> <p>① = Value f min ② = Value f max</p> <p> Caution! The frequency output responds differently, depending on the parameters set in the various functions. Some examples of parameter settings and their effect on the frequency output are given in the following section.</p> <p> Note!</p> <ul style="list-style-type: none"> ■ The appropriate unit is taken from the group SYSTEM UNITS (see Page 10).

Function description PULSE/FREQUENCY OUTPUT

OUTPUT SIGNAL

 **Note!**
 Function is not available unless the FREQUENCY setting was selected in the OPERATING MODE function.

For selecting the output configuration of the frequency output.

Options:
 0 = PASSIVE - POSITIVE
 1 = PASSIVE - NEGATIVE


Factory setting: PASSIVE - POSITIVE

Explanation


- PASSIVE = power is supplied to the frequency output by means of an external power supply.

Configuring the output signal level (POSITIVE or NEGATIVE) determines the quiescent behaviour (at zero flow) of the frequency output.
 The internal transistor is activated as follows:

- If POSITIVE is selected, the internal transistor is activated with a **positive** signal level.
- If NEGATIVE is selected, the internal transistor is activated with a **negative** signal level (0 V).


 **Note!**
 With the passive output configuration, the output signal levels of the frequency output depend on the external circuit (see examples).

Example for passive output circuit (PASSIVE)
 If PASSIVE is selected, the frequency output is configured as an open collector.






A0001225

① = Open Collector
 ② = External power supply

 **Note!**
 For continuous currents up to 25 mA ($I_{max} = 250 \text{ mA} / 20 \text{ ms}$).


Example for output configuration PASSIVE-POSITIVE:
 Output configuration with an external pull-up resistance.
 In the quiescent state (at zero flow), the output signal level at the terminals is 0 V.

F06-xxxxxxx-04-xx-xx-xx-000

① = Open Collector
 ② = Pull-Up-Resistance
 ③ = Transistor activation in "POSITIVE" quiescent state (at zero flow)
 ④ = Output signal level in quiescent state (at zero flow)





In the operating status (flow present), the output signal level changes from 0 V to a positive voltage level.
















F06-xxxxxxx-04-xx-xx-xx-004

(continued on next page)

Function description PULSE/FREQUENCY OUTPUT	
<p>OUTPUT SIGNAL (Continued)</p>	<p>Example for output configuration PASSIVE-POSITIVE: Output configuration with an external pull-down resistance. In the quiescent state (at zero flow), a positive voltage level is measured via the pull-down resistance.</p> <div style="text-align: center;"> </div> <p style="text-align: right;">F06-xxxxxxx-04-xx-xx-xx-001</p> <p>① = Open Collector ② = Pull-Down-Resistance ③ = Transistor activation in "POSITIVE" quiescent state (at zero flow) ④ = Output signal level in quiescent state (at zero flow)</p> <p>In the operating status (flow present), the output signal level changes from a positive voltage level to 0 V.</p> <div style="text-align: center;"> </div> <p style="text-align: right;">F06-xxxxxxx-04-xx-xx-xx-006</p> <p>Example for output configuration PASSIVE-NEGATIVE: Output configuration with an external pull-up resistance. In the quiescent state (at zero flow), the output signal level at the terminals is at a positive voltage level.</p> <div style="text-align: center;"> </div> <p style="text-align: right;">F06-xxxxxxx-04-xx-xx-xx-002</p> <p>① = Open Collector ② = Pull-Up-Resistance ③ = Transistor activation in "NEGATIVE" quiescent state (at zero flow) ④ = Output signal level in quiescent state (at zero flow)</p> <p>In the operating status (flow present), the output signal level changes from a positive voltage level to 0 V.</p> <div style="text-align: center;"> </div> <p style="text-align: right;">F06-xxxxxxx-04-xx-xx-xx-006</p>








Function description PULSE/FREQUENCY OUTPUT	
TIME CONSTANT	<p> Note! This function is not available unless the FREQUENCY setting was selected in the function OPERATION MODE.</p> <p>Use this function to enter a time constant defining how the frequency output signal reacts to severely fluctuating measured variables, either very quickly (enter a low time constant) or with damping (enter a high time constant).</p> <p>User input: Floating-point number 0.00...100.00 s</p> <p>Factory setting: 0.00 s</p>
FAILSAFE MODE	<p> Note! This function is not available unless the FREQUENCY setting was selected in the function OPERATION MODE.</p> <p>For safety reasons it is advisable to ensure that the frequency output assumes a predefined state in the event of a fault. Use this function to define this state. The setting you select here affects only the frequency output. It has no effect on other outputs or the display (e.g. totalizers).</p> <p>Options: FALLBACK VALUE Output is 0 Hz. FAILSAFE LEVEL Output is the frequency specified in the FAILSAFE VALUE function. HOLD VALUE Measuring value output is based on the last measuring value saved before the error occurred ACTUAL VALUE Measuring value output based on the actual flow measurement (fault is ignored).</p> <p>Factory setting: FALLBACK VALUE</p>
FAILSAFE VALUE	<p> Note! This function is not available unless FREQUENCY was selected in the OPERATION MODE function and FAILSAFE LEVEL was selected in the function FAILSAFE MODE.</p> <p>Use this function to define the frequency that the measuring device should output in the event of a fault.</p> <p>User input: max. 4-digit number: 0...1250 Hz</p> <p>Factory setting: 1250 Hz</p>
ACTUAL FREQUENCY	<p> Note! This function is not available unless the FREQUENCY setting was selected in the function OPERATION MODE.</p> <p>Use this function to view the computed actual value of the output frequency.</p> <p>Display: 0 ...1250 Hz</p>






Function description PULSE/FREQUENCY OUTPUT	
SIMULATION FREQUENCY	<p> Note! This function is not available unless the FREQUENCY setting was selected in the function OPERATION MODE.</p> <p>Use this function to activate simulation of the frequency output.</p> <p>Options: OFF ON</p> <p>Factory setting: OFF</p> <p> Note!</p> <ul style="list-style-type: none"> ■ The “SIMULATION FREQUENCY OUTPUT” message indicates that simulation is active. ■ The measuring device continues to measure while simulation is in progress, i.e. the current measuring values are output correctly via the other outputs. <p> Caution! The setting is not saved if the power supply fails.</p>
VALUE SIMULATION FREQUENCY	<p> Note! This function is not available unless FREQUENCY was selected in the OPERATION MODE function and the function VALUE SIMULATION FREQUENCY is active (= ON).</p> <p>Use this function to define a selectable frequency value (e.g. 500 Hz) to be output at the frequency output. This is used to test downstream devices and the measuring device itself.</p> <p>User input: 0 ...1250 Hz</p> <p>Factory setting: 0 Hz</p> <p> Caution! The setting is not saved if the power supply fails.</p>
ASSIGN PULSE	<p> Note! This function is not available unless the PULSE setting was selected in the function OPERATION MODE.</p> <p>Use this function to assign a measured variable to the pulse output.</p> <p>Options: OFF VOLUME FLOW</p> <p>Factory setting: VOLUME FLOW</p> <p> Note! If you select OFF, the only functions shown in this function group are the functions ASSIGN PULSE and OPERATION MODE.</p>

Function description PULSE/FREQUENCY OUTPUT	
PULSE VALUE	<p> Note! This function is not available unless the PULSE setting was selected in the function OPERATION MODE.</p> <p>Use this function to define the flow at which a pulse is triggered. These pulses can be totalled by an external totalizer and the total flow since measuring started can be recorded in this way.</p> <p>User input: 5-digit floating-point number</p> <p>Factory setting: 1 1/pulse Corresponds to the factory setting for the pulse value (see Page 68).</p> <p> Note! The appropriate unit is taken from the group SYSTEM UNITS, (see Page 10).</p>
PULSE WIDTH	<p> Note! This function is not available unless the PULSE setting was selected in the function OPERATION MODE.</p> <p>Use this function to enter the maximum pulse width of the output pulses.</p> <p>User input: 0.5...2000 ms</p> <p>Factory setting: 100 ms</p> <p>Pulse output is always with the pulse width (B) entered in this function. The intervals (P) between the individual pulses are automatically adjusted. However, they must at least correspond to the pulse width (B = P).</p> <div style="text-align: center;">  </div> <p style="text-align: right; font-size: small;">A0001233</p> <p>B = Pulse width entered (the illustration applies to positive pulses) P= Intervals between the individual pulses</p> <p> Note! When entering the pulse width, select a value that can still be processed by an external totalizer (e.g. mechanical totalizer, PLC, etc.).</p> <p> Caution! If the pulse number or frequency resulting from the pulse value entered, (see function PULSE VALUE on Page 37), and from the current flow is too large to maintain the pulse width selected (the interval P is smaller than the pulse width B entered), a system error message (pulse memory) is generated after buffering/balancing.</p>




Function description PULSE/FREQUENCY OUTPUT	
<p>OUTPUT SIGNAL</p>	<p> Note! Function is not available unless the PULSE setting was selected in the OPERATION MODE function.</p> <p>For selecting the output configuration of the pulse output.</p> <p>Options: 0 = PASSIVE - POSITIVE 1 = PASSIVE - NEGATIVE</p> <p>Factory setting: PASSIVE - POSITIVE</p> <p>Explanation</p> <ul style="list-style-type: none"> ■ PASSIVE = power is supplied to the pulse output by means of an external power supply. <p>Configuring the output signal level (POSITIVE or NEGATIVE) determines the quiescent behaviour (at zero flow) of the pulse output. The internal transistor is activated as follows:</p> <ul style="list-style-type: none"> ■ If POSITIVE is selected, the internal transistor is activated with a positive signal level. ■ If NEGATIVE is selected, the internal transistor is activated with a negative signal level (0 V). <p> Note! With the passive output configuration, the output signal levels of the pulse output depend on the external circuit (see examples).</p> <p>Example for passive output circuit (PASSIVE) If PASSIVE is selected, the pulse output is configured as an open collector.</p> <div style="text-align: center;"> </div> <p style="text-align: right;">A0001225</p> <p>① = Open Collector ② = External power supply</p> <p> Note! For continuous currents up to 25 mA ($I_{max} = 250 \text{ mA} / 20 \text{ ms}$).</p> <p>Example for output configuration PASSIVE-POSITIVE: Output configuration with an external pull-up resistance. In the quiescent state (at zero flow), the output signal level at the terminals is 0 V.</p> <div style="text-align: center;"> </div> <div style="display: flex; justify-content: space-around;"> <div style="text-align: center;"> <p>③</p> </div> <div style="text-align: center;"> <p>④</p> </div> </div> <p style="text-align: right;">F06-xxxxxxx-04-xx-xx-xx-000</p> <p>① = Open Collector ② = Pull-Up-Resistance ③ = Transistor activation in "POSITIVE" quiescent state (at zero flow) ④ = Output signal level in quiescent state (at zero flow)</p> <p>In the operating status (flow present), the output signal level changes from 0 V to a positive voltage level.</p> <div style="text-align: center;"> </div> <p style="text-align: right;">F06-xxxxxxx-04-xx-xx-xx-004</p> <p>(continued on next page)</p>





Function description PULSE/FREQUENCY OUTPUT	
<p>OUTPUT SIGNAL (Continued)</p>	<p>Example for output configuration PASSIVE-POSITIVE: Output configuration with an external pull-down resistance. In the quiescent state (at zero flow), a positive voltage level is measured via the pull-down resistance.</p> <div style="text-align: center;"> </div> <p style="text-align: right;">F06-xxxxxxx-04-xx-xx-xx-001</p> <p>① = Open Collector ② = Pull-Down-Resistance ③ = Transistor activation in "POSITIVE" quiescent state (at zero flow) ④ = Output signal level in quiescent state (at zero flow)</p> <p>In the operating status (flow present), the output signal level changes from a positive voltage level to 0 V.</p> <div style="text-align: center;"> </div> <p style="text-align: right;">F06-xxxxxxx-04-xx-xx-xx-006</p> <p>Example for output configuration PASSIVE-NEGATIVE: Output configuration with an external pull-up resistance. In the quiescent state (at zero flow), the output signal level at the terminals is at a positive voltage level.</p> <div style="text-align: center;"> </div> <p style="text-align: right;">F06-xxxxxxx-04-xx-xx-xx-002</p> <p>① = Open Collector ② = Pull-Up-Resistance ③ = Transistor activation in "NEGATIVE" quiescent state (at zero flow) ④ = Output signal level in quiescent state (at zero flow)</p> <p>In the operating status (flow present), the output signal level changes from a positive voltage level to 0 V.</p> <div style="text-align: center;"> </div> <p style="text-align: right;">F06-xxxxxxx-04-xx-xx-xx-006</p>



Function description PULSE/FREQUENCY OUTPUT	
FAILSAFE MODE	<p> Note! This function is not available unless the PULSE setting was selected in the function OPERATION MODE.</p> <p>For safety reasons it is advisable to ensure that the pulse output assumes a predefined state in the event of a fault. Use this function to define this state. The setting you select here affects only the pulse output. It has no effect on other outputs or the display (e.g. totalizers).</p> <p>Options: FALLBACK VALUE Output is 0 pulses.</p> <p>HOLD VALUE Measuring value output based on the last measuring value saved before the error occurred.</p> <p>ACTUAL VALUE Measuring value output based on the current flow measurement. The fault; is ignored.</p> <p>Factory setting: FALLBACK VALUE</p>
SIMULATION PULSE	<p> Note! This function is not available unless the PULSE option was selected in the OPERATING MODE function.</p> <p>Use this function to activate simulation of the pulse output.</p> <p>Options: OFF</p> <p>COUNTDOWN The pulses specified in the VALUE SIMULATION PULSE function are output.</p> <p>CONTINUOUSLY Pulses are continuously output with the pulse width specified in the PULSE WIDTH function. Simulation is started once the CONTINUOUSLY option is confirmed with the  key.</p> <p> Note! Simulation is started by confirming the CONTINUOUSLY option with the  key. The simulation can be switched off again via the SIMULATION PULSE function.</p> <p>Factory setting: OFF</p> <p> Note!</p> <ul style="list-style-type: none"> ■ The notice message #631 “SIM. PULSE” indicates that simulation is active. ■ The on/off ratio is 1:1 for both types of simulation. ■ The measuring device continues to measure while simulation is in progress, i.e. the current measured values are output correctly via the other outputs. <p> Caution! The setting is not saved if the power supply fails.</p>

Function description PULSE/FREQUENCY OUTPUT	
<p>VALUE SIMULATION PULSE</p>	<p> Note! This function is not available unless the COUNTDOWN option was selected in the SIMULATION PULSE function.</p> <p>Use this function to specify the number of pulses (e.g. 50) which are output during the simulation. This value is used to test downstream devices and the measuring device itself. The pulses are output with the pulse width specified in the PULSE WIDTH function. The on/off ratio is 1:1.</p> <p>Simulation is started once the specified value is confirmed with the  key. The display remains at 0 if the specified pulses have been output.</p> <p>User input: 0...10,000</p> <p>Factory setting: 0</p> <p> Note! Simulation is started by confirming the simulation value with the  key. The simulation can be switched off again via the SIMULATION PULSE function.</p> <p> Caution! The setting is not saved if the power supply fails.</p>

11 Group STATUS OUTPUT

Function description STATUS OUTPUT	
This group is not available unless the measuring device is equipped with a status output.	
ASSIGN STATUS OUTPUT	<p>Use this function to assign a switching function to the status output.</p> <p>Options: OFF ON (operation) FAULT MESSAGE NOTICE MESSAGE FAULT MESSAGE & NOTICE MESSAGE FLOW DIRECTION VOLUME FLOW LIMIT VALUE SOUND VELOCITY LIMIT VALUE FLOW VELOCITY LIMIT VALUE</p> <p>Factory setting: FAULT MESSAGE</p> <p> Note!</p> <ul style="list-style-type: none"> ■ The behaviour of the status output is a normally closed behaviour, in other words the output is closed (transistor conductive) when normal, error-free measuring is in progress. ■ It is very important to read and comply with the information on the switching characteristics of the status output, (see Page 45). ■ If you select OFF, the only function shown in this function group is the function ASSIGN STATUS OUTPUT.
ON-VALUE	<p> Note!</p> <p>This function is not available unless LIMIT VALUE or FLOW DIRECTION was selected in the function ASSIGN STATUS OUTPUT.</p> <p>Use this function to assign a value to the switch-on point (status output pulls up). The value can be equal to, greater than or less than the switch-off point. Positive and negative values are permissible.</p> <p>User input: 5-digit floating-point number</p> <p>Factory setting: 0 [unit]</p> <p> Note!</p> <ul style="list-style-type: none"> ■ The appropriate unit is taken from the group SYSTEM UNITS, (see Page 10). ■ Only the switch-on point is available for flow direction output (no switch-off point). If you enter a value not equal to the zero flow (e.g. 5), the difference between the zero flow and the value entered corresponds to half the switchover hysteresis.

Function description STATUS OUTPUT	
OFF-VALUE	<p> Note! This function is not available unless LIMIT VALUE was selected in the ASSIGN STATUS OUTPUT function.</p> <p>Use this function to assign a value to the switch-off point (status output drops out). The value can be equal to, greater than or less than the switch-on point. Positive and negative values are permissible.</p> <p>User input: 5-digit floating-point number</p> <p>Factory setting: 0 [unit]</p> <p> Note!</p> <ul style="list-style-type: none"> ■ The appropriate unit is taken from the group SYSTEM UNITS, (see Page 10). ■ If SYMMETRY is selected in the function MEASURING MODE (Page 58) and values with different signs are entered for the switch-on and switch-off points, the notice message “INPUT RANGE EXCEEDED” appears.
TIME CONSTANT	<p>Use this function to enter a time constant defining how the measuring signal reacts to severely fluctuating measured variables, either very quickly (enter a low time constant) or with damping (enter a high time constant). The purpose of damping, therefore, is to prevent the status output changing state continuously in response to fluctuations in flow.</p> <p>User input: fixed-point number 0.00...100.00 s</p> <p>Factory setting: 0.00 s</p>
ACTUAL STATUS	<p>Use this function to check the current status of the status output.</p> <p>Display: NOT CONDUCTIVE CONDUCTIVE</p>
SIMULATION SWITCH POINT	<p>Use this function to activate simulation of the status output.</p> <p>Options: OFF ON</p> <p>Factory setting: OFF</p> <p> Note!</p> <ul style="list-style-type: none"> ■ The “SIMULATION SWITCH POINT” message indicates that simulation is active. ■ The measuring device continues to measure while simulation is in progress, i.e. the current measuring values are output correctly via the other outputs. <p> Caution! The setting is not saved if the power supply fails.</p>

Function description STATUS OUTPUT	
VALUE SIMULATION SWITCH POINT	<p> Note! This function is not available unless the function SIMULATION SWITCH POINT is active (= ON).</p> <p>Use this function to define the switching response of the status output during the simulation. This is used to test downstream devices and the measuring device itself.</p> <p>Options: NOT CONDUCTIVE CONDUCTIVE</p> <p>Factory setting: NOT CONDUCTIVE</p> <p> Caution! The setting is not saved if the power supply fails.</p>

11.1 Information on the response of the status output


General

If you have configured the status output for “LIMIT VALUE” or “FLOW DIRECTION”, you can configure the requisite switch points in the functions ON-VALUE and OFF-VALUE. When the measured variable in question reaches these predefined values, the status output switches as shown in the illustrations below.

Status output configured for limit value

The status output switches as soon as the measured variable undershoots or overshoots a defined switch point. Application: Monitoring flow or process-related boundary conditions.

Measured variable




- ① = ON \leq SWITCH-OFF POINT (maximum safety)
- ② = ON $>$ SWITCH-OFF POINT (minimum safety)
- ③ = Status output switched off (not conductive)

A0001235

Status output configured for flow direction

The value entered in the function SWITCH-ON POINT defines the switch point for the positive and negative directions of flow. If, for example, the switch point entered is $+1 \text{ m}^3/\text{h}$, the status output switches off at $-1 \text{ m}^3/\text{h}$ (not conductive) and switches on again at $+1 \text{ m}^3/\text{h}$ (conductive). Set the switch point to 0 if your process calls for direct switchover (no switching hysteresis). If low flow cut off is used, it is advisable to set hysteresis to a value greater than or equal to the low flow cut off.



Switch-off point/switch-on point Measured variable

















- a = Status output conductive
- b = Status output not conductive




A0001236



11.2 Switching action of the status output

Function	Status	Open collector response (transistor)
ON (operation)	System in measuring mode	conductive  A0001237
	System not in measuring mode (power supply failed)	not conductive  A0001238



Function	Status	Open collector response (transistor)
Fault message	System OK	conductive 
	(System or process error) Fault → Error response of outputs/inputs and totalizer	not conductive 
Notice message	System OK	conductive 
	(System or process error) Fault → Continuation of measuring	not conductive 
Fault message or notice message	System OK	conductive 
	(System or process error) Fault → Response to error or Note → Continuation of measuring	not conductive 
Flow direction	Forward 	conductive 
	Reverse 	not conductive 
Limit value – Volume flow – Sound velocity – Flow velocity	Limit value not overshoot or undershot 	conductive 
	Limit value overshoot or undershot 	not conductive 

12 Group STATUS INPUT




Function description STATUS INPUT	
This group is not available unless the measuring device is equipped with a status input.	
ASSIGN STATUS INPUT	<p>Use this function to assign a switching function to the status input.</p> <p>Options: OFF RESET TOTALIZER1 POSITIVE ZERO RETURN ZERO POINT ADJUSTMENT RESET TOTALIZER2 RESET ALL TOTALIZERS</p> <p>Factory setting: OFF</p> <p> Note! Positive zero return is active as long as the active level is available at the status input (continuous signal). All other assignments react to a change in level (pulse) at the status input.</p>
ACTIVE LEVEL	<p>Use this function to define whether the assigned switch function, (see function ASSIGN STATUS INPUT) is released or sustained when the level is present (HIGH) or not present (LOW).</p> <p>Options: HIGH LOW</p> <p>Factory setting: HIGH</p>
MINIMUM PULSE WIDTH	<p>Use this function to define a minimum pulse width which the input pulse must achieve in order to trigger the selected switching function.</p> <p>User input: 0...100 ms</p> <p>Factory setting: 50 ms</p>
SIMULATION STATUS INPUT	<p>Use this function to activate simulation of the status input, i.e. to trigger the function assigned to the status input, (see function ASSIGN STATUS INPUT on Page 42).</p> <p>Options: OFF ON</p> <p>Factory setting: OFF</p> <p> Note!</p> <ul style="list-style-type: none"> ■ The “SIMULATION STATUS INPUT” message indicates that simulation is active. ■ The measuring device continues to measure while simulation is in progress, and the current measuring values are output correctly via the outputs. <p> Caution! The setting is not saved if the power supply fails.</p>



Function description STATUS INPUT	
VALUE SIMULATION STATUS INPUT	<p> Note! This function is not available unless the function SIMULATION STATUS INPUT is active (= ON).</p> <p>Use this function to select the level to be simulated at the status input.</p> <p>Options: HIGH LOW</p> <p>Factory setting: LOW</p> <p> Caution! The setting is not saved if the power supply fails.</p>

13 Group COMMUNICATION




Function description COMMUNICATION	
TAG NAME	<p>Use this function to enter a tag name for the measuring device. You can edit and read this tag name via the local display or the HART protocol.</p> <p>User input: max. 8-character text, permitted characters are: A-Z, 0–9, +, -, punctuation marks</p> <p>Factory setting: “ _ _ _ _ _ _ _ _ ” (without text)</p>
TAG DESCRIPTION	<p>Use this function to enter a tag description for the measuring device. You can edit and read this tag description at the local display or via the HART protocol.</p> <p>User input: max. 16-character text, permitted characters are: A-Z, 0–9, +, -, punctuation marks</p> <p>Factory setting: “ _ _ _ _ _ _ _ _ _ _ _ _ _ _ _ _ ” (without text)</p>
FIELD BUS ADDRESS	<p>Use this function to define the address for the exchange of data with the HART protocol.</p> <p>User input: 0...15</p> <p>Factory setting: 0</p> <p> Note! Addresses 1...15: a constant 4 mA current is applied.</p>
HART PROTOCOL	<p>Use this function to display if the HART protocol is active.</p> <p>Display: OFF = HART protocol not active ON = HART protocol active</p> <p> Note! The HART protocol is activated by selecting 4–20 mA HART or 4–20 mA (25 mA) HART in the function CURRENT SPAN (see Page 27).</p>
MANUFACT. ID	<p>Use this function to view the manufacturer number in decimal numerical format.</p> <p>Display: 17 (≅ 11 hex) for Endress+Hauser</p>
DEVICE ID	<p>Use this function to view the device ID in hexadecimal numerical format.</p> <p>Display: 58 (≅ 88 dez) for Prosonic Flow 90</p>

14 Group PROCESS PARAMETER



Function description PROCESS PARAMETER	
ASSIGN LOW FLOW CUT OFF	<p>Use this function to assign the switch point for the low flow cut off.</p> <p>Options: OFF VOLUME FLOW</p> <p>Factory setting: VOLUME FLOW</p>
ON-VALUE LOW FLOW CUT OFF	<p> Note! This function is not available unless VOLUME FLOW was selected in the function ASSIGN LOW FLOW CUT OFF.</p> <p>Use this function to enter the switch-on point for low flow cut off. Low flow cut off is active if the value entered is not equal to 0. The sign of the flow value is highlighted on the display to indicate that low flow cut off is active.</p> <p>User input: 5-digit floating-point number</p> <p>Factory setting: 0 l/s</p> <p> Note! The appropriate unit is taken from the group SYSTEM UNITS, (see Page 10).</p>
OFF-VALUE LOW FLOW CUT OFF	<p> Note! This function is not available unless VOLUME FLOW was selected in the function ASSIGN LOW FLOW CUT OFF.</p> <p>Use this function to enter the switch-off point for low flow cut off. Enter the switch-off point as a positive hysteresis value from the switch-on point.</p> <p>User input: Integer 0...100%</p> <p>Factory setting: 50%</p> <p>Example:</p> <div data-bbox="802 1496 1305 1682" data-label="Figure"> </div> <p>Q = Flow [volume/time] t = Time H = Hysteresis a = ON-VALUE LOW FLOW CUT OFF = 200 dm³/h b = OFF-VALUE LOW FLOW CUT OFF = 10% c = Low flow cut off active 1 = Low flow cut off is switched on at 200 dm³/h 2 = Low flow cut off is switched off at 220 dm³/h</p> <p style="text-align: right;">A0001245</p>

Function description PROCESS PARAMETER	
ZEROPOINT ADJUSTMENT	<p>Use this function to start zero point adjustment automatically. The new zero point determined by the measuring system is adopted by the ZERO POINT function, (see P. 63).</p> <p>Options: CANCEL START</p> <p>Factory setting: CANCEL</p> <p> Caution! Before carrying this out, please refer to the Operating Instructions Proline Prosonic Flow 90 (BA 068D/06/en/...) for a detailed description of the procedure for zero point adjustment.</p> <p> Note!</p> <ul style="list-style-type: none"> ■ Programming is locked during zero point adjustment. The message “ZEROPOINT ADJUST RUNNING” appears on the display. ■ If the zero point adjustment is not possible, (e.g. if $v > 0.1$ m/s), or has been canceled, then the alarm message “ZERO ADJUST NOT POSSIBLE” is shown on the display. ■ If the Prosonic Flow 90 electronics are fitted with a status input, then the zero point adjustment can also be activated by using this input.


15 Group PIPE DATA




Function description PIPE DATA	
PIPE STANDARD	<p>Use this function to select a pipe standard.</p> <p>Options: OTHER DIN: PN10, PN16, 28610, 28614, 28615, 28619 ANSI: SCHEDULE 40, SCHEDULE 80 AWWA: CLASS 50, CLASS 53, CLASS 55</p> <p> Note! The selection specifies the values for the following functions:</p> <ul style="list-style-type: none"> ■ PIPE MATERIAL ■ SOUND VELOCITY PIPE ■ LINER MATERIAL <p>If you edit these functions the pipe standard will be reset to the option OTHERS.</p> <p>Factory setting: DIN PN10</p>
NOMINAL DIAMETER	<p> Note! This function does not appear if the option OTHERS was selected in the function PIPE STANDARD.</p> <p>Use this function to select the nominal diameter of the pipe.</p> <p>Options: OTHER DN: 25/1", 40/1½", 50/2", 80/3", 100/4", 150/6", 200/8", 250/10", 300/12", 400/16", 450/18", 500/20", 600/24", 700/28", 750/30", 800/32", 900/36", 1000/40", 1200/48", 1400/54", 1500/60", 1600/64", 1800/72", 2000/80"</p> <p> Note! The selection specifies the values for the following functions:</p> <ul style="list-style-type: none"> ■ CIRCUMFERENCE ■ PIPE DIAMETER ■ WALL THICKNESS <p>If you edit these functions the pipe standard will be reset to the option OTHERS and the function NOMINAL DIAMETER does not appear.</p> <p>Factory setting: 80/3"</p>
PIPE MATERIAL	<p>This function displays the pipe material determined via the values entered in the function PIPE STANDARD. If you edit the predetermined value the pipe standard will be reset to the option OTHERS and the function NOMINAL DIAMETER does not appear.</p> <p>If a pipe standard was not available for selection and the selection OTHER was made in the function PIPE STANDARD the pipe material must be entered here.</p> <p>Options: CARBON STEEL, DUCTILE IRON, STAINLESS STEEL, SS ANSI 304, SS ANSI 316, SS ANSI 347, SS ANSI 410, SS ANSI 430, ALLOY C, PVC, PE, LDPE, HDPE, GRP, PVDF, PA, PP, PTFE, GLASS PYREX, ASBESTOS CEMENT, OTHER</p> <p>Factory setting: STAINLESS STEEL</p>


Function description PIPE DATA	
SOUND VELOCITY PIPE	<p>This function displays the sound velocity in the pipe determined via the values entered in the function PIPE STANDARD. If you edit the predetermined value the pipe standard will be reset to the option OTHERS and the function NOMINAL DIAMETER does not appear.</p> <p>If a pipe standard was not available for selection and the selection OTHER was made in the function PIPE STANDARD the sound velocity must be entered here.</p> <p>User input: Fixed-point number 800...6500 m/s</p> <p>Factory setting: 3120 m/s</p>
CIRCUMFERENCE	<p>This function displays the outer circumference of the pipe determined via the values entered in the function NOMINAL DIAMETER. If you edit the predetermined value the pipe standard will be reset to the option OTHERS and the function NOMINAL DIAMETER does not appear.</p> <p>If a nominal diameter was not available for selection and the selection OTHER was made in the function NOMINAL DIAMETER the outer circumference must be entered here.</p> <p>User input: Fixed-point number 31.4...15708.0 mm</p> <p>Factory setting: 279.3 mm</p>
PIPE DIAMETER	<p>This function displays the outer diameter of the pipe determined via the values entered in the function NOMINAL DIAMETER. If you edit the predetermined value the pipe standard will be reset to the option OTHERS and the function NOMINAL DIAMETER does not appear.</p> <p>If a nominal diameter was not available for selection and the selection OTHER was made in the function NOMINAL DIAMETER the outer diameter must be entered here.</p> <p>User input: Fixed-point number 10.0...5000.0 mm</p> <p>Factory setting: 88.9 mm</p>
WALL THICKNESS	<p>This function displays the thickness of the pipe walls determined via the values entered in the function NOMINAL DIAMETER. If you edit the predetermined value the pipe standard will be reset to the option OTHERS and the function NOMINAL DIAMETER does not appear.</p> <p>If a nominal diameter was not available for selection and the selection OTHER was made in the function NOMINAL DIAMETER the thickness of the pipe wall must be entered here.</p> <p>User input: Fixed-point number 0.1...100.0 mm</p> <p>Factory setting: 3.2 mm</p>

Function description PIPE DATA	
LINER MATERIAL	<p>This function displays the liner material of the pipe determined via the values entered in the function PIPE STANDARD. If you edit the predetermined value the pipe standard will be reset to the option OTHERS and the function NOMINAL DIAMETER does not appear.</p> <p>If a pipe standard was not available for selection and the selection OTHER was made in the function PIPE STANDARD the liner material must be entered here.</p> <p>Options: LINER NONE MORTAR RUBBER TAR EPOXY OTHERS</p> <p>Factory setting: LINER NONE</p>
SOUND VELOCITY LINER	<p> Note! This function does not appear if the option LINER NONE was selected in the function LINER MATERIAL</p> <p>This function displays the sound velocity of the liner determined via the values entered in the function LINER MATERIAL. If you edit the predetermined value the liner material will be reset to the option OTHERS.</p> <p>If a liner material was not available for selection and the selection OTHER was made in the function LINER MATERIAL the sound velocity of the liner must be entered here.</p> <p>User input: Fixed-point number 800...6500 m/s</p> <p>Factory setting: Depends on the setting selected in the function LINER MATERIAL</p>
LINER THICKNESS	<p> Note! This function does not appear if the option LINER NONE was selected in the function LINER MATERIAL</p> <p>Use this function to enter the thickness of the liner.</p> <p>User input: Fixed-point number 0.1...100 mm</p> <p>Factory setting: 0 mm</p>




16 Group LIQUID DATA




Function description LIQUID DATA	
LIQUID	<p>Use this function to select the liquid in the pipe.</p> <p>Options: WATER, SEAWATER, DISTILLED WATER, AMMONIA, ALCOHOL, BENZENE, BROMIDE, ETHANOL, GLYCOL, KEROSENE, MILK, METHANOL, TOLUOL, LUBE OIL, FUEL OIL, PETROL, OTHERS</p> <p> Note! The selection specifies the values for the sound velocity and viscosity. If OTHER is selected, these must be entered via the SOUND VELOCITY LIQUID and VISCOSITY functions.</p> <p>Factory setting: WATER</p>
TEMPERATURE	<p>Use this function to enter the process temperature of the liquid. Via the sound velocity, the value influences the determination of the sensor distance. Enter the process temperature at normal operating conditions to achieve an optimum configuration of the measuring system.</p> <p>User input: Fixed-point number $-273.15\text{ °C} \dots 726.85\text{ °C}$ (0...1000 K)</p> <p>Factory setting: 20 °C</p>

Function description LIQUID DATA	
SOUND VELOCITY LIQUID	<p>This function displays the sound velocity of the liquid determined via the values entered in the functions LIQUID and TEMPERATURE. If you edit the predetermined value the function LIQUID will be reset to the option OTHERS. If a liquid was not available for selection and the selection OTHER was made in the function LIQUID the sound velocity must be entered here.</p> <p>Transmitter search range: The measuring device searches for the measuring signal within a defined sound velocity range. You specify the search range in the SOUND VELOCITY NEGATIVE (6545) and SOUND VELOCITY POSITIVE (6546) functions. An error message is displayed if the sound velocity of the liquid exceeds the search range.</p> <p> Note! We recommend you select a smaller search range by unfavourable signal conditions (signal strength < 50%).</p> <div style="text-align: center;">  </div> <p style="text-align: right;">A0001246</p> <p><i>1 = Sound velocity liquid</i> <i>② = Lower search range: defined in the SOUND VELOCITY NEGATIVE function</i> <i>③ = Upper search range: defined in the SOUND VELOCITY POSITIVE function</i></p> <p>User input: Fixed-point number 400...3000 m/s</p> <p>Factory setting: 1485 m/s</p>
VISCOSITY	<p>This function displays the viscosity of the liquid. This is determined via the values entered in the LIQUID and TEMPERATURE functions. If you edit the predetermined value the function LIQUID will be reset to the option OTHERS.</p> <p>If the liquid is not available for selection in the LIQUID function and the OTHER option was selected the viscosity must be entered here.</p> <p>User input: Fixed-point number 0.0...5000.0 cSt</p> <p>Factory setting: 1 mm²/s</p>
SOUND VELOCITY NEGATIVE	<p>Use this function to specify the lower search range for the sound velocity of the liquid.</p> <p>User input: Fixed-point number 0...1000 m/s</p> <p>Factory setting: 500 m/s</p> <p> Note! Pay particular attention to the information in the SOUND VELOCITY LIQUID function.</p>


Function description LIQUID DATA	
SOUND VELOCITY POSITIVE	<p>Use this function to specify the upper search range for the sound velocity of the liquid.</p> <p>User input: Fixed-point number 0...1000 m/s</p> <p>Factory setting: 300 m/s</p> <p> Note! Pay particular attention to the information in the SOUND VELOCITY LIQUID function.</p>

17 Group SYSTEM PARAMETERS



Function description SYSTEM PARAMETERS	
INSTALLATION DIRECTION SENSOR	<p>Use this function to reverse the sign of the flow quantity, if necessary.</p> <p>Options: NORMAL INVERSE</p> <p>Factory setting: NORMAL</p>
MEASURING MODE	<p>Use this function to define the measuring mode for all outputs.</p> <p>Options: STANDARD SYMMETRY</p> <p>Factory setting: STANDARD</p> <p>The responses of the individual outputs in each of the measuring modes are described in detail on the following pages:</p> <p>Current output and frequency output STANDARD</p> <p>The output signals of the current and frequency outputs are proportional to the measured variable assigned. Only positive flow components are totalled. Negative components are not taken into account.</p> <p>Example for current output:</p>  <p style="text-align: right;">A0001248</p> <p>SYMMETRY</p> <p>The output signals of the current and frequency outputs are independent of the direction of flow (absolute amount of the measured variable).</p> <p>The "VALUE 20 mA" or "VALUE-f HIGH" ③ (e.g. backflow) corresponds to the mirrored VALUE 20 mA or VALUE-f HIGH ② (e.g. flow). Positive and negative flow components are taken into account.</p> <p>Example for current output:</p>  <p style="text-align: right;">A0001249</p> <p> Note! The direction of flow can be output via the configurable status output.</p>




Function description SYSTEM PARAMETERS	
<p>MEASURING MODE (Contd)</p>	<p>Pulse output STANDARD Only positive flow components are totalled. Negative components are not taken into account.</p> <p>SYMMETRY Positive and negative flow components are taken into account.</p> <p> Note! The direction of flow can be output via the configurable status output.</p> <p>Status output</p> <p> Note! The information is only applicable if LIMIT VALUE was selected in the function ASSIGN STATUS OUTPUT.</p> <p>STANDARD The status output signal switches at the defined switch points.</p> <p>SYMMETRY The status output signal switches at the defined switch points, irrespective of the sign. In other words, if you define a switch point with a positive sign, the status output signal switches as soon as the value is reached in the negative direction (negative sign), (see illustration).</p> <p>Example for the SYMMETRY measuring mode: Switch-on point: Q = 4 Switch-off point: Q = 10</p> <p>① = Status output switched on (conductive) ② = Status output switched off (not conductive)</p> <div style="text-align: center;">  </div>

A0001247



Function description SYSTEM PARAMETERS	
POSITIVE ZERO RETURN	<p>Use this function to interrupt evaluation of measured variables. This is necessary when a piping system is being cleaned, for example. This setting acts on all function and outputs of the measuring device.</p> <p>Options: OFF ON Signal output is set to the “ZERO FLOW” value.</p> <p>Factory setting: OFF</p>
FLOW DAMPING	<p>Use this function to set the filter depth of the digital filter. The sensitivity of the measurement signal can be reduced with respect to interference peaks (e.g. in the event of a high solid content, gas bubbles in the fluid etc.). The reaction time of the measuring device increases with the filter setting.</p> <p>User input: 0 ...15</p> <p>Factory setting: 0</p> <p> Note! The system damping acts on all functions and outputs of the measuring device.</p>

18 Group SENSOR DATA









Function description SENSOR DATA	
<p>You can set the parameter settings for the ultrasonic sensors in this group.</p>	
MEASUREMENT	<p>Options: CLAMP ON INSERTION</p> <p>Factory setting: CLAMP ON</p>
SENSOR TYPE	<p>Options: W-CL-05F-L-B ¹⁾ W-CL-1F-L-B ¹⁾ W-CL-2F-L-B ¹⁾ P-CL-05F-L-B ¹⁾ P-CL-1F-L-B ¹⁾ P-CL-2F-L-B ¹⁾ U-CL-2F-L-A ¹⁾ P-CL-05F-M-B ¹⁾ P-CL-1F-M-B ¹⁾ P-CL-2F-M-B ¹⁾ W-IN-1F-L-B ²⁾</p> <p>Factory setting: W-CL-2F-L-B</p> <p> Note! ¹⁾ This option is not available unless CLAMP ON was selected in the function MEASUREMENT. ²⁾ This option is not available unless INSERTION was selected in the function MEASUREMENT.</p>
SENSOR CONFIGURATION	<p>Use this function to select the configuration for the ultrasonic sensors, e.g. the number of traverses (in the clamp-on design).</p> <p>Options: NO. TRAVERSE: 1 ¹⁾ NO. TRAVERSE: 2 ¹⁾ NO. TRAVERSE: 3 ¹⁾ NO. TRAVERSE: 4 ¹⁾ SINGLE PATH ²⁾</p> <p>Factory setting: NO. TRAVERSE: 2</p> <p> Note! <ul style="list-style-type: none"> ■ When using the U-Sensor it is always required to set this function to “NO. TRAVERSE: 2” ■ For flow measurement it is basically not recommended to set this function to “NO. TRAVERSE: 3”. ¹⁾ This option is not available unless CLAMP ON was selected in the function MEASUREMENT. ²⁾ This option is not available unless INSERTION was selected in the function MEASUREMENT.</p>




Function description SENSOR DATA	
CABLE LENGTH	<p>Use this function to select the length of the sensor cable.</p> <p>Options: LENGTH 5m/15 feet LENGTH 10m/30 feet LENGTH 15m/45 feet LENGTH 30m/90 feet</p> <p>Factory setting: LENGTH 5m/15 feet</p>
POSITION SENSOR	<p>Use this function to view the position of both sensors on the rail.</p> <p> Note! This function is not available unless CLAMP ON was selected in the function MEASUREMENT and the number of traverses is 2 or 4, (see function SENSOR CONFIGURATION).</p> <p>Display: 4-digit number combination</p>
WIRE LENGTH	<p>The wire length for assembling the sensors at the correct distance apart appears on the display.</p> <p> Note! This function is not available unless CLAMP ON was selected in the function MEASUREMENT and the number of traverses is 1 or 3, (see SENSOR CONFIGURATION).</p> <p>Display: max. 4-digit number, including unit (e.g. 200 mm)</p>
SENSOR DISTANCE	<p>The distance between sensor 1 and sensor 2 as a length measurement appears on the display.</p> <p>Display: max. 4-digit number, including unit (e.g. 200 mm)</p>
PATH LENGTH	<p>The path length appears on the display.</p> <p> Note! This function is not available unless INSERTION was selected in the function MEASUREMENT.</p> <p>Display: max. 4-digit number, including unit (e.g. 200 mm)</p>

19 Group CALIBRATION DATA





Function description CALIBRATION DATA	
P-FACTOR	<p>This function displays the p-factor.</p> <p>The p-factor indicates the influence of the velocity distribution of the flow profile inside the pipe; it is dependent on the reynolds number. The p-factor varies in the range 0.75...0.95. If the displayed value ranges 0.75...0.94 the measurement will have a reduced linearity.</p>
ZERO POINT	<p>Use this function to call up or manually change the zero point correction currently being used.</p> <p>User input: 5-digit floating-point number, including unit and sign (e.g. +0010.0 ns)</p>
CORRECTION FACTOR	<p>Use this function to enter a correction factor at the client's site.</p> <p>User input: 5-digit floating-point number</p> <p>Factory setting: 1.000 (no correction)</p>
DEVIATION SENSOR DISTANCE	<p>Use this function to enter a deviation value for the sensor distance.</p> <p> Note! This function is not available unless INSERTION was selected in the function MEASUREMENT.</p> <p>User input: 5-digit floating-point number, including unit and sign (e.g. +2.000 mm)</p> <p>Factory setting: 0 mm</p>
DEVIATION PATH LENGTH	<p>Use this function to enter a deviation value for the path length.</p> <p> Note! This function is not available unless INSERTION was selected in the function MEASUREMENT.</p> <p>User input: 5-digit floating-point number, including unit and sign (e.g. +2.000 mm)</p> <p>Factory setting: 0 mm</p>

20 Group SUPERVISION

Function description SUPERVISION	
ACTUAL SYSTEM CONDITION	<p>Use this function to check the current system condition.</p> <p>Display: "SYSTEM OK" or the fault / notice message with the highest priority.</p>
PREVIOUS SYSTEM CONDITIONS	<p>Use this function to view the fifteen most recent error and notice messages since measuring last started.</p> <p>Display: The last 15 fault/ notice messages.</p>
ASSIGN SYSTEM ERROR	<p>Use this function to view all system errors and the associated error categories (fault message or notice message). If you select a single system error you can change its error category.</p> <p>Options: CANCEL List of system errors with an icon preceding each entry.</p> <p> Note!</p> <ul style="list-style-type: none"> ■ Press the  - key twice to call up the ERROR CATEGORY function. ■ Use the  - key combination or select "CANCEL" in the system error list to exit the function. ■ A list of possible system errors is provided in the Operating Instructions Proline Prosonic Flow 90 (BA 068D/06/en/...).
ERROR CATEGORY	<p>Use this function to define whether a system error triggers a notice message or a fault message. If you select "FAULT MESSAGES", all outputs respond to an error in accordance with their defined error response patterns.</p> <p>Options: NOTICE MESSAGES (display only) FAULT MESSAGES (outputs and display)</p> <p> Note! Press the  - key twice to call up the function ASSIGN SYSTEM ERROR.</p>
ASSIGN PROCESS ERROR	<p>Use this function to view all process errors and the associated error categories (fault message or notice message). If you select a single process error you can change its error category.</p> <p>Options: CANCEL List of process errors with an icon preceding each entry.</p> <p> Note!</p> <ul style="list-style-type: none"> ■ Press the  - key twice to call up the ERROR CATEGORY function. ■ Use the  - key combination or select "CANCEL" in the process error list to exit the function. ■ A list of possible process errors is provided in the Operating Instructions Proline Prosonic Flow 90 (BA 068D/06/en/...).

Function description SUPERVISION	
ERROR CATEGORY	<p>Use this function to define whether a process error triggers a notice message or a fault message. If you select "FAULT MESSAGES", all outputs respond to an error in accordance with their defined error response patterns.</p> <p>Options: NOTICE MESSAGES (display only) FAULT MESSAGES (outputs and display)</p> <p> Note! Press the  - key twice to call up the ASSIGN PROCESS ERROR function.</p>
ALARM DELAY	<p>Use this function to define a time span in which the criteria for an error have to be satisfied without interruption before an error or notice message is generated.</p> <p>Depending on the setting and the type of error, this suppression acts on the:</p> <ul style="list-style-type: none"> ■ Display ■ Status output ■ Current output ■ Frequency output <p>User input: 0 s...100 s (in steps of one second)</p> <p>Factory setting: 0 s</p> <p> Caution! If this function is activated error and notice messages are delayed by the time corresponding to the setting before being forwarded to the higher-order controller (process controller, etc.). It is therefore imperative to check in advance in order to make sure whether a delay of this nature could affect the safety requirements of the process. If error and notice messages cannot be suppressed, a value of 0 seconds must be entered here.</p>
SYSTEM RESET	<p>Use this function to perform various resets of the measuring system.</p> <p>Options: NO RESTART SYSTEM (restart without interrupting power supply)</p> <p>Factory setting: NO</p>
OPERATION HOURS	<p>The hours of operation of the device appear on the display.</p> <p>Display: Depends on the number of hours of operation elapsed: Hours of operation < 10 hours → display format = 00:00:00 (hr:min:sec) Hours of operation 10...10,000 hours → display format = 0000:00 (hr:min) Hours of operation > 10,000 hours → display format = 000000 (hr)</p>


21 Group SIMULATION SYSTEM

Function description SIMULATION SYSTEM	
SIMULATION FAILSAFE MODE	<p>Use this function to set all inputs, outputs and the totalizer to their defined failsafe modes, in order to check whether they respond correctly. During this time, the words "SIMULATION FAILSAFE MODE" appear on the display.</p> <p>Options: ON OFF</p> <p>Factory setting: OFF</p>
SIMULATION MEASURED VARIABLE	<p>Use this function to set all inputs, outputs and the totalizer to their defined flow-response modes, in order to check whether they respond correctly. During this time, the words "SIMULATION MEASURAND" appear on the display.</p> <p>Options: OFF VOLUME FLOW SOUND VELOCITY</p> <p>Factory setting: OFF</p> <p> Caution!</p> <ul style="list-style-type: none"> ■ The measuring device cannot be used for measuring while this simulation is in progress. ■ The setting is not saved if the power supply fails.
VALUE SIMULATION MEASURED VARIABLE	<p> Note! This function is not available unless the function SIMULATION MEASURED VARIABLE is active.</p> <p>Use this function to define a free selectable value (e.g. 12 m³/s). This is used to test downstream devices and the measuring device itself.</p> <p>User input: 5-digit floating-point number</p> <p>Factory setting: 0</p> <p> Caution! The setting is not saved if the power supply fails.</p> <p> Note! The appropriate unit is taken from the group SYSTEM UNITS, (see Page 10)</p>

22 Group SENSOR VERSION

Function description SENSOR VERSION	
SERIAL NUMBER	Use this function to view the serial number of the sensor.

23 Group AMPLIFIER VERSION

Function description AMPLIFIER VERSION	
DEVICE SOFTWARE	Displays the current device software version.
HARDWARE REVISION NUMBER AMPLIFIER	Use this function to view the hardware revision number of the amplifier.
LANGUAGE GROUP	<p>Use this function to view the language group.</p> <p>The following language groups can be ordered: WEST EU / USA, EAST EU / SCAND., ASIA, CHINESE.</p> <p>Display: available language group</p> <p> Note!</p> <ul style="list-style-type: none"> ■ The language options of the available language group are displayed in the LANGUAGE (2000) function. ■ You can change the language group via the configuration software ToF Tool – Fieldtool Package. Please do not hesitate to contact your Endress+Hauser sales office if you have any questions.
SOFTWARE REVISION NUMBER AMPLIFIER	Use this function to view the software revision number of the amplifier.
I/O-MODULE TYPE	Use this function to view the configuration of the I/O module complete with terminal numbers.
HARDWARE REVISION NUMBER I/O-MODUL	Use this function to view the hardware revision number of the I/O module.
SOFTWARE REVISIONNUMBER I/O-MODUL	Use this function to view the software revision number of the I/O module.

24 Factory settings

24.1 SI units

Parameter	Factory setting
Nominal diameter	80 [mm]
Low flow cut off ($v \approx 0,04$ m/s)	12 [dm ³ /min]
Full scale value ($v \approx 2,5$ m/s)	750 [dm ³ /min]
Pulse value	5,0 [dm ³]
Unit totalizer	dm ³
Unit length	mm
Unit temperature	° C

24.2 US units (for USA and Canada only)

Parameter	Factory setting
Nominal diameter	3"
Low flow cut off ($v \approx 0,04$ m/s)	2,5 [gal/min]
Full scale value ($v \approx 2,5$ m/s)	200 [gal/min]
Pulse value	2,0 [gal]
Unit totalizer	gal
Unit length	mm
Unit temperature	° C

24.3 Language

Country	Language
Australia	English
Austria	Deutsch
Belgium	English
Canada	English
China	Chinese
Czech Republic	Czech
Denmark	English
England	English
Finland	Suomi
France	Francais
Germany	Deutsch
Hong Kong	English
Hungary	English
India	English
Indonesia	Bahasa Indonesia
Instruments International	English
Italy	Italiano
Japan	Japanese
Malaysia	English
Netherlands	Nederlands
Norway	Norsk
Poland	Polish
Portugal	Portuguese
Russia	Russian
Singapore	English
South Africa	English
Spain	Espanol
Sweden	Svenska
Switzerland	Deutsch
Thailand	English
USA	English

Index

Numerics

0_4 mA value	28
100% Value	20
20 mA value	28

A

Access code	19
Active level	47
Actual	
Current	29
Frequency	35
Status output	43
Alarm delay	65
Amplifier version	67
Assign	
Current output	26
Display line 1	20
Display line 2	20
Frequency	31
Low flow cut off	50
Process error	64
Pulse	36
Status input	47
Status output	42
System error	64
Totalizer	23

B

Bus address	49
-------------------	----

C

Cable length	62
Calibration data	63
Circumference (pipe)	53
Communication	49
Contrast LCD	21
Correction factor	63
Current output	26
Current range	27
Current system conditions	64

D

Define private code	19
Deviation	
Path length	63
Sensor spacing	63
Device ID	49
Device Software	
Amplifier	67
Diameter (pipe)	53
Display	
Damping	21
Format	21
Test	22

E

End value frequency	31
---------------------------	----

Error category

Process error	65
System error	64

F

Factory settings	68
Failsafe mode	
Current output	29
Frequency output	35
Pulse output	40
Flow damping	60
Format (display)	21
Frequency	
Max. value	32
Min. value	32
Output	31
Function matrix	
Layout and use	7
Overview	8

G

Group

Amplifier version	67
Calibration data	63
Communication	49
Current output	26
Liquid data	55
Measuring values	9
Operation	18
Pipe data	52
Process parameter	50
Pulse/Frequency output	31
Quick Setup	13
Sensor data	61
Sensor version	67
Simulation system	66
Status input	47
Status output	42
Supervision	64
System parameter	58
System units	10
Totalizer	23
User interface	20

H

Hardware revision number

Amplifier	67
I/O Module	67
HART Protocol	49

I

I/O module type (input/output type)	67
Installation direction sensor	58

L

Language	18
Language group	

Amplifier	67	Overview	13
Length (unit)	11	Sensor	14
Liner		R	
Material	54	Reset totalizer	24
Sound velocity	54	S	
Thickness	54	Sensor configuration	61
Liquid (function)	55	Sensor data	61
Liquid data (group)	55	Sensor position	62
Low flow cut off		Sensor serial number	67
Off-value	50	Sensor spacing	62
Switch-on point	50	Sensor type	61
M		Simulation	
Manufacturer No.	49	Current	29
Max. liquid sound velocity	57	Failsafe mode	66
Measurement	61	Frequency	36
Measuring mode	58	Measured variable	66
Measuring values	9	Status input	47
Min. liquid sound velocity	56	Switch point	43
Min. pulse width	47	Simulation system	66
N		Software revision number	
Nominal diameter	52	Amplifier	67
O		I/O Module	67
Off-Value		Sound velocity	
Low flow cut off	50	Liner	54
Status output	43	Liquid	56
Operation	18	Pipe	53
Operation mode	31	Standard pipe	52
Output signal		Status access	19
Frequency output	33, 34	Status input	47
Pulse	38, 39	Status output	42
Overflow	23	Flow direction	45
P		General	45
Path length	62	Limit value	45
P-factor	63	Switching action	45
Pipe		Sum	23
Circumference	53	Supervision	64
Diameter	53	Switch-on point	
Liner material	54	Low flow cut off	50
Nominal diameter	52	Status output	42
Sound velocity	53	System	
Standard	52	Reset	65
Wall thickness	53	System condition	
Pipe data (group)	52	Actual	64
Pipe material	52	Previous	64
Position sensor	62	System parameter	58
Positive zero return	60	System units	10
Previous system conditions	64	T	
Private code	19	Tag	
Process parameter	50	Description	49
Pulse output	31	Name	49
Pulse value	37	Temperature	
Pulse width	37	Function	55
Q		Unit	11
Quick Setup		Test display	22
Commissioning	16	Time constant	
		Current output	29
		Frequency output	35

Status output	43
Totalizer	23, 24
Assign	23
U	
Unit	
Length	11
Temperature	11
Totalizer	23
Velocity	12
Viscosity	11
Volume	11
Volume flow	10
User interface	20
V	
Value	
0_4 mA	28
20 mA	28
f High	32
f Low	32
Failsafe level	35
Value simulation	
Current	30
Frequency	36
Measured variable	66
Status input	48
Switch point	44
Velocity (unit)	12
Viscosity	
Function	56
Unit	11
Volume	
Flow	9
Flow (unit)	10
Unit	11
W	
Wall thickness (pipe)	53
Wire length	62
Z	
Zero point	63
Zero point adjustment	51

www.endress.com/worldwide

Endress+Hauser 
People for Process Automation